

Using the Aware Installer or updating your Aware using a Mac computer or SD card reader

May 2011

There is a video available on <http://www.airspaceaware.com/support/instructional-videos/>

If you are using the Aware installer, please follow these instructions

- 1) Download the latest airspace definition by clicking on the Download button on the Customer Downloads page of the Aware site and saving it to your computer. If you have downloaded a previous database, please delete it.
- 2) If it is your first time please download the Aware Airspace Updater.
- 3) Turn on the Aware and allow it to load into the map screen.
- 4) Plug the Aware into your computer using the supplied USB lead or insert the memory card from the unit into your SD card reader if you have one. **(We recommend using an SD card reader)**
- 5) Run "Aware system update" from "Airbox Aerospace Ltd" directory of your Start menu, under All Programs.
- 6) The system will check for new versions of the installer on the internet, you will then be presented with the disclaimer, which you must accept if you wish to use the software. You should notice the Aware screen changes to a blue "Update in Progress" screen, this highlights that you are starting the process.
- 7) Now, on your computer, press the 'Browse' button and find where you downloaded the airspace to.
- 8) Press the 'refresh' button.
- 9) Click on the dropdown box next to the refresh button and select 'Activesync device' (or if using an SD card reader then Removable Disk Drive J/K/L etc. depending on what your computer states is the drive letter.
- 10) Press 'Update' and select yes when the message asks if you are sure you want to continue.
- 11) The update may take a few minutes, after which the system will reboot itself. **DO NOT UNPLUG THE DEVICE AT THIS TIME.**
- 12) When the device has updated, the PC will display a success message. Now press 'finish'.

If you are updating with a Mac, you will need a memory card reader, in which case, please follow these instructions:

- 1) Switch off the Aware device.
- 2) Remove the memory card and place it in your computer, and note which drive/removable disk the SD is.
- 3) Download the airspace update file to your desktop, please note on the downloads page that **Mac users must always download the software update file** (second download option)
- 4) Rename it as a **.zip** type rather than a **.update**.
- 5) Once it is AiracNumber.zip you can double click on the file and then select all the files in it and copy them all to the SD card. Some files will be replacing existing ones on your SD card so just agree when you are prompted to overwrite files.

Once this is done you can safely remove the SD card from your computer (usually at the bottom right corner you get the option to safely remove the removable disk) and then insert the SD card back into your Aware. Then you are able to power the unit back up and you should see that your airspace warnings are up to date.

Airbox staff are on hand to help you during normal working hours if you need further assistance.